

## Departure:

SID	RWY	Trans	Exit Fix	Exit Route	Available Cruising Flight Level	Direction	Reaching Cruising Level			
BEKOL3A BEKOL3C	07R 07L	(NONE)	BEKOL	A461	Mainland China RVSM Levels	Guangzhou FIR	BEKOL at S0480-(FL157) or above			
					S0420-(FL138) S0450-(FL148)	Landing ZGGG	BEKOL			
					S0180-(5900ft)	Landing ZGSZ				
LAKES3A LAKES3C	07R 07L	V1	DOTMI	A470	290 330 350 390	Guangzhou FIR	SOUSA (42 NM before DOTMI)			
					S0450-(FL148)	Landing ZGOW				
					S0630-(FL207) S0690-(FL226)	Landing ZSAM, ZSQZ				
		V13	LELIM	M503	Mainland China Eastbound RVSM Levels	Guangzhou FIR	AROXA			
OCEAN2A OCEAN2C	07R 07L	V2	ELATO	A1	Odd number flight levels at or below FL270	Taipei FIR	20nm before ELATO			
					G581	Odd number flight levels at or below FL270	ENVAR			
					M750	Eastbound RVSM FL410 FL450 FL490				
					V4	NOMAN	A461	290 330 370 410	Manila FIR	20nm before NOMAN
							M501	290 330 370 410	Manila FIR	20nm before SABNO
SKATE	KAPLI	G86	290 330 370 390 410	Taipei FIR	20nm before KAPLI					
PECAN1A PECAN1C	07R 07L	V10	SIKOU	A202	S1040-(FL341) S1160-(FL381) S1220-(FL401)	Points beyond ASSAD	DONKI (41nm before SIKOU)			
					S0660-(FL217) S0720-(FL236)	Landing ZJHK				
					S0840-(FL276)	Landing ZJSY				
				R339	Mainland China Westbound RVSM Levels	Points beyond ZGNN				
					S0600-(FL197)	Landing ZGZJ, ZGNU				
					S0720-(FL236) S0780-(FL256)	Landing ZGBH, ZGNN				
V11	IDOSI	A1/(P901)	280 300 340 380 400 430	Sanya FIR	SURFA (23 NM before IDOSI)					
V12	EPDOS	L642	280 310 320 350 360 390 400	Sanya FIR	EPDOS					

## Arrival:

From fix	Arrival routes	STAR	Descent planning	Speed Control	ILS approach
ABBEY	Holding Pattern	ABBEY3A	MUSEL at FL130	280 KIAS at MUSEL	LIMES transition between 3000ft and 6000ft
BETTY	Holding Pattern	BETTY2A	MANGO at FL130	280 KIAS at MANGO	
CANTO	Holding Pattern	CANTO3A	MURRY at FL130	280 KIAS at CANTO	ILS07L: TONIC 2000ft / turn right 040° / intercept 1700ft (PAX aircraft) (Freq: 111.100)
CARSO	(M7711) - Q1 - V551	BETTY2A	CYBER at FL260 and MANGO at FL130	280 KIAS at MANGO	
DOTMI	A470 - V511	ABBEY3A	MUSEL at FL130	280 KIAS at MUSEL	
LELIM	M503 - V591	ABBEY3A	MUSEL at FL130	280 KIAS at MUSEL	
ELATO	A1/G581 - V521	ABBEY3A	MUSEL at FL130	280 KIAS at MUSEL	
IDOSI	A1/P901 - V561	CANTO3A	MAPLE at FL260 and MURRY at FL130	280 KIAS at ROCCA	ILS 07R: STELA 2000ft / turn right 040° / intercept 1700ft (Cargo/business/GA) (Freq: 109.300)
NOMAN	A461/M501 - V531	BETTY2A	SONNY at FL260 and MANGO at FL130	280 KIAS at MANGO	
SABNO	A583 - V541	BETTY2A	SONNY at FL260 and MANGO at FL130	280 KIAS at MANGO	
SIERA	R473	SIERA7A/C	MURRY at FL130	280 KIAS at SIERA	
SIKOU	A202/R339 - V571	CANTO3A	MAPLE at FL260 and MURRY at FL130	280 KIAS at ROCCA	

## Squawk Code Assignment:

IFR Departure	VFR Departure	Others
5301-5377	5261-5277	5201-5257

## Departure:

SID	RWY	Trans	Exit Fix	Exit Route	Available Cruising Flight Level	Direction	Reaching Cruising Level		
ATENA1E (ATENA2A) ATENA1F (ATENA2C)	07R 07L	(NONE)	BEKOL	A461	Mainland China RVSM Levels	Guangzhou FIR	BEKOL at S0480-(FL157) or above		
					S0420-(FL138) S0450-(FL148)	Landing ZGGG	BEKOL		
					S0180-(5900ft)	Landing ZGSZ			
VENGO1E (VENGO1A) VENGO1F (VENGO1C)	07R 07L	V1	DOTMI	A470	290 330 350 390	Guangzhou FIR	SOUSA (42 NM before DOTMI)		
					S0450-(FL148)	Landing ZGOW			
					S0630-(FL207) S0690-(FL226)	Landing ZSAM, ZSQZ			
		V13	LELIM	M503	Mainland China Eastbound RVSM Levels	Guangzhou FIR	AROXA		
RASSE1E (RASSE3A) RASSE1F (RASSE3C)	07R 07L	V2	ELATO	A1	Odd number flight levels at or below FL270	Taipei FIR	20nm before ELATO		
				G581	Odd number flight levels at or below FL270				
				M750	Eastbound RVSM FL410 FL450 FL490	Taipei FIR	ENVAR		
SKATE1E (SKATE3A) SKATE1F (SKATE3C)	07R 07L	V4	NOMAN	A461	290 330 370 410	Manila FIR	20nm before NOMAN		
				M501	290 330 370 410				
				V5	SABNO	A583	290 330 370 410	Manila FIR	20nm before SABNO
				SKATE	KAPLI	G86	290 330 370 390 410	Taipei FIR	20nm before KAPLI
TITAN1E (PECAN1A) TITAN1F (PECAN1C)	07R 07L	V10	SIKOU	A202	S1040-(FL341) S1160-(FL381) S1220-(FL401)	Points beyond ASSAD	DONKI (41nm before SIKOU)		
					S0660-(FL217) S0720-(FL236)	Landing ZJHK			
					S0840-(FL276)	Landing ZJSY			
					Mainland China Westbound RVSM Levels	Points beyond ZGNN			
					S0600-(FL197)	Landing ZGZJ, ZGNU			
					S0720-(FL236) S0780-(FL256)	Landing ZGBH, ZGNN			
	V11	IDOSI	A1/(P901)	280 300 340 380 400 430	Sanya FIR	SURFA (23 NM before IDOSI)			
	V12	EPDOS	L642	280 310 320 350 360 390 400	Sanya FIR	EPDOS			

## Arrival:

From fix	Arrival routes	STAR	Descent planning	Speed Control	ILS approach
ABBEY	Holding Pattern	ABBEY3A	MUSEL at FL130	280 KIAS at MUSEL	LIMES transition between 3000ft and 6000ft
BETTY	Holding Pattern	BETTY2A	MANGO at FL130	280 KIAS at MANGO	
CANTO	Holding Pattern	CANTO3A	MURRY at FL130	280 KIAS at CANTO	ILS07L: TONIC 2000ft / turn right 040° / intercept 1700ft (PAX aircraft) (Freq: 111.100)
CARSO	(M7711) - Q1 - V551	BETTY2A	CYBER at FL260 and MANGO at FL130	280 KIAS at MANGO	
DOTMI	A470 - V511	ABBEY3A	MUSEL at FL130	280 KIAS at MUSEL	
LELIM	M503 - V591	ABBEY3A	MUSEL at FL130	280 KIAS at MUSEL	
ELATO	A1/G581 - V521	ABBEY3A	MUSEL at FL130	280 KIAS at MUSEL	
IDOSI	A1/P901 - V561	CANTO3A	MAPLE at FL260 and MURRY at FL130	280 KIAS at ROCCA	ILS 07R: STELA 2000ft / turn right 040° / intercept 1700ft (Cargo/business/GA) (Freq: 109.300)
NOMAN	A461/M501 - V531	BETTY2A	SONNY at FL260 and MANGO at FL130	280 KIAS at MANGO	
SABNO	A583 - V541	BETTY2A	SONNY at FL260 and MANGO at FL130	280 KIAS at MANGO	
SIERA	R473	SIERA7A/C	MURRY at FL130	280 KIAS at SIERA	
SIKOU	A202/R339 - V571	CANTO3A	MAPLE at FL260 and MURRY at FL130	280 KIAS at ROCCA	

## Squawk Code Assignment:

IFR Departure	VFR Departure	Others
5301-5377	5261-5277	5201-5257

## Departure:

SID	RWY	Trans	Exit Fix	Exit Route	Available Cruising Flight Level	Direction	Reaching Cruising Level	
BEKOL2B BEKOL2D	25L 25R	(NONE)	BEKOL	A461	Mainland China RVSM Levels	Guangzhou FIR	BEKOL at S0480-(FL157) or above	
					S0420-(FL138) S0450-(FL148)	Landing ZGGG	BEKOL	
					S0180-(5900ft)	Landing ZGSZ		
LAKES2B LAKES2D	25L 25R	V1	DOTMI	A470	290 330 350 390	Guangzhou FIR	SOUSA (42 NM before DOTMI)	
					S0450-(FL148)	Landing ZGOW		
					S0630-(FL207) S0690-(FL226)	Landing ZSAM, ZSQZ		
					S0690-(FL226) S0750-(FL246) S0810-(FL266) 290	Landing ZSFZ, ZSWY		
OCEAN2B OCEAN2D	25L 25R	V13	LELIM	M503	Mainland China Eastbound RVSM Levels	Guangzhou FIR	AROXA	
					A1	Odd number flight levels at or below FL270	Taipei FIR	20nm before ELATO
					G581	Odd number flight levels at or below FL270	Taipei FIR	ENVAR
					M750	Eastbound RVSM FL410 FL450 FL490	Taipei FIR	20nm before NOMAN
					A461	290 330 370 410	Manila FIR	20nm before SABNO
					M501	290 330 370 410	Manila FIR	20nm before KAPLI
PECAN1B PECAN1D	25L 25R	V10	SIKOU	A202	S1040-(FL341) S1160-(FL381) S1220-(FL401)	Points beyond ASSAD	DONKI (41nm before SIKOU)	
					S0660-(FL217) S0720-(FL236)	Landing ZJHK		
					S0840-(FL276)	Landing ZJSY		
					Mainland China Westbound RVSM Levels	Points beyond ZGNN		
					R339	S0600-(FL197)		Landing ZGZJ, ZG NU
V11	IDOSI	A1/(P901)	L642	S0720-(FL236) S0780-(FL256)	Landing ZGBH, ZGNN	SURFA (23 NM before IDOSI)		
				280 300 340 380 400 430	Sanya FIR	EPDOS		
				280 310 320 350 360 390 400	Sanya FIR			

Cross TROUT FL140 or above

## Arrival:

From fix	Arrival routes	STAR	Descent planning	Speed Control	ILS approach
ABBEY	Holding Pattern	ABBEY2B	MUSEL at FL130	280 KIAS at MUSEL	TD between 6000ft and 8000ft
BETTY	Holding Pattern	BETTY2B	MANGO at FL130	280 KIAS at MANGO	
CANTO	Holding Pattern	CANTO2B	MURRY at FL150	280 KIAS at CANTO	TORUB Transition 25R SABOG Transition 25L
CARSO	(M7711) - Q1 - V551	BETTY2B	CYBER at FL260 and MANGO at FL130	280 KIAS at MANGO	
DOTMI	A470 - V511	ABBEY2B	MUSEL at FL130	280 KIAS at MUSEL	ILS25R: at TORUB turn left to RIVER at 4500ft/ intercept at 4500ft (Freq 110.900)
LELIM	M503 - V591	ABBEY2B	MUSEL at FL130	280 KIAS at MUSEL	(RWY25R for PAX a/c arrival)
ELATO	A1/G581 - V521	ABBEY2B	MUSEL at FL130	280 KIAS at MUSEL	
IDOSI	A1/P901 - V561	CANTO2B	MAPLE at FL260 and MURRY at FL150	280 KIAS at ROCCA	ILS 25L: at SABOG turn left to LOTUS at 4500ft/ intercept at 4500ft (Freq 108.900)
NOMAN	A461/M501 - V531	BETTY2B	SONNY at FL260 and MANGO at FL130	280 KIAS at MANGO	
SABNO	A583 - V541	BETTY2B	SONNY at FL260 and MANGO at FL130	280 KIAS at MANGO	
SIERA	R473	SIERA6B/D	MURRY at FL150	280 KIAS at SIERA	
SIKOU	A202/R339 - V571	CANTO2B	MAPLE at FL260 and MURRY at FL150	280 KIAS at ROCCA	

## Squawk Code Assignment:

IFR Departure	VFR Departure	Others
5301-5377	5261-5277	5201-5257

## Departure:

SID	RWY	Trans	Exit Fix	Exit Route	Available Cruising Flight Level	Direction	Reaching Cruising Level
SHL9D (SHL1D*) (SHL2D#)	16	(NONE)	SHL	A461 (N) G471 (E) W22 (N)	Mainland China RVSM Levels	Guangzhou FIR	In Guangzhou FIR (Zhuhai Approach provides TMA control)
MIPAG9D (MIPAG1D*) (MIPAG2D#)	16	(NONE)	MIPAG	W21 to CEN (NW) to GLN (SE)	Mainland China RVSM Levels	Guangzhou FIR	In Guangzhou FIR (Zhuhai Approach provides TMA control)
NLG9D (NLG1D*) (NLG2D#)	16	(NONE)	NLG	V19 (W)	Mainland China RVSM Levels	Guangzhou FIR	In Guangzhou FIR (Zhuhai Approach provides TMA control)
BIGRO9D (BIGRO1D*) (BIGRO2D#)	16	(NONE)	BIRGO	G221 (W) R200 (W)	Mainland China RVSM Levels	Guangzhou FIR	In Guangzhou FIR (Zhuhai Approach provides TMA control)
SOUSA2P	16	V1	DOTMI	A470	290 330 350 390	Guangzhou FIR	SOUSA (42 NM before DOTMI)
					S0450-(FL148)	Landing ZGOW	
					S0690-(FL226) S0750-(FL246)	Landing ZSAM, ZSQZ	
V13	LELIM	M503	330	Landing ZSPD	AROXA		
			330, 350	ZSQD,ZSYT,ZYTL			
CONGA2P	16	SKATE	KAPLI	G86	290 330 370 390 410	Taipei FIR	20nm before KAPLI
		V3	ENVAR	M750	Eastbound RVSM FL410 FL450 FL490	Taipei FIR	ENVAR
GRUPA2P	16	V4	NOMAN	A461	290 330 370 410	Manila FIR	20nm before NOMAN
				M501	290 330 370 410		
				V5	SABNO		
ALLEY2P	16	V10	SIKOU	A202	S1040-(FL341) S1160-(FL381) S1220-(FL401)	Points beyond ASSAD	DONKI (41nm before SIKOU)
					S0660-(FL217) S0720-(FL236)	Landing ZJHK	
					S0840-(FL276)	Landing ZJSY	
				Mainland China Westbound RVSM Levels	Points beyond ZGNN		
				R339	S0600-(FL197)	Landing ZGZJ, ZGNN	
				S0720-(FL236) S0780-(FL256)	Landing ZGBH, ZGNN		
V31	IDOSI	A1/(P901)	280 300 340 380 400 430	Sanya FIR	SURFA (23 NM before IDOSI)		
V32	EPDOS	L642	280 310 320 350 360 390 400	Sanya FIR	EPDOS		

## Squawk Code Assignment:

IFR Departure	VFR Departure	Others
3521-3537	3521-3537	5201-5257

## Departure:

SID	RWY	Trans	Exit Fix	Exit Route	Available Cruising Flight Level	Direction	Reaching Cruising Level			
SHL5D (SHL6D*) (SHL7D#)	34	(NONE)	SHL	A461 (N) G471 (E) W22 (N)	Mainland China RVSM Levels	Guangzhou FIR	In Guangzhou FIR <b>(Zhuhai Approach provides TMA control)</b>			
MIPAG5D (MIPAG6D*) (MIPAG7D#)	34	(NONE)	MIPAG	W21 to CEN (NW) to GLN (SE)	Mainland China RVSM Levels	Guangzhou FIR	In Guangzhou FIR <b>(Zhuhai Approach provides TMA control)</b>			
NLG5D (NLG6D*) (NLG7D#)	34	(NONE)	NLG	V19 (W)	Mainland China RVSM Levels	Guangzhou FIR	In Guangzhou FIR <b>(Zhuhai Approach provides TMA control)</b>			
BIGRO4D (BIGRO8D*) (BIGRO7D#)	34	(NONE)	BIRGO	G221 (W) R200 (W)	Mainland China RVSM Levels	Guangzhou FIR	In Guangzhou FIR <b>(Zhuhai Approach provides TMA control)</b>			
SOUSA3T (SOUSA2V+)	34	V1	DOTMI	A470	290 330 350 390	Guangzhou FIR	SOUSA (42 NM before DOTMI)			
					S0450-(FL148)	Landing ZGOW				
SOUSA3U (SOUSA2W+)	25	V13	LELIM	M503	S0690-(FL226) S0750-(FL246)	Landing ZSAM, ZSQZ				
					S0690-(FL226) S0750-(FL246) S0810-(FL266) 290	Landing ZSFZ, ZSWY				
					330	Landing ZSPD				
					330, 350	ZSQD,ZSYT,ZYTL	AROXA			
CONGA2T (CONGA1V+)	34	SKATE	KAPLI	G86	290 330 370 390 410	Taipei FIR	20nm before KAPLI			
CONGA3U (CONGA2W+)		25	V3	ENVAR	M750	Eastbound RVSM FL410 FL450 FL490	Taipei FIR	ENVAR		
GRUPA2T (GRUPA1V+)	34	V4	NOMAN	A461	290 330 370 410	Manila FIR	20nm before NOMAN			
GRUPA3U (GRUPA2W+)				25	V5			SABNO	A583	290 330 370 410
ALLEY2T (ALLEY1V+)	34	V10	SIKOU	A202	S1040-(FL341) S1160-(FL381) S1220-(FL401)	Points beyond ASSAD	DONKI (41nm before SIKOU)			
									S0660-(FL217) S0720-(FL236)	Landing ZJHK
					S0840-(FL276)	Landing ZJSY				
					Mainland China Westbound RVSM Levels	Points beyond ZGNN				
ALLEY2U (ALLEY1W+)	25	V31	IDOSI	A1/(P901)	S0600-(FL197)	Landing ZGZJ, ZGNU				
									S0720-(FL236) S0780-(FL256)	Landing ZGBH, ZGNN
									280 300 340 380 400 430	Sanya FIR
		V32	EPDOS	L642	280 310 320 350 360 390 400	Sanya FIR	EPDOS			

\* when ZAO DVOR is unserviceable + when LKC DVOR is unserviceable  
# basic RNP1, GNSS required

## Squawk Code Assignment:

IFR Departure	VFR Departure	Others
3521-3537	3521-3537	5201-5257

## From Hong Kong FIR:

FROM	Arrival Route	Descent Planning	Initial Fix	RWY	STAR	DESCEND FIX/ALT/SPEED CONTROL
DOTMI	A470-DOTMI-SAMMI-J101			34	SMT4A	HAZEL (IAF)/FL110
ELATO	A1/G581-J101	NEDLE at FL230	SMT	16	SMT5B	HAZEL/FL110 INDUS/2700m MC514/2100m MC516 or ZUH (IAF)/1800m
DUMOL	M771/M772-J103-ROBIN-CHALI	ISBAN at FL200		34	CHALI4A	CHALI/FL110 RUNLI/9000ft MC611 (IAF)/6000ft
IDOSI	A1/P901-IDOSI-DASON-J104	COTON FL120	CHALI	16	CHALI5B	CHALI/FL110
SABNO	A583-SABNO-TOFEE-ARROW-J103-ROBIN	ISBAN at FL200				RUNLI/9000ft INDUS/2700m MC514/2100m MC516 or ZUH (IAF)/1800m
SIKOU	A202/R339-J104	COTON FL120				

## From Guangzhou FIR: (\*Zhuhai Approach is responsible for these STARs. See LOA for details.)

FROM	Arrival Route	Descent Planning	Initial Fix	RWY	STAR	DESCEND FIX/ALT/SPEED CONTROL
BIGRO	G221/R200/V20	GURIN at 2700m(8860ft) UJ at 2400m(7880ft)	BIGRO	34	BIGRO6A BIGRO7A	UJ (IAF)/2400m(7880ft)
				16	BIGRO9A BIGRO1A	MC516 or ZUH (IAF)/1800m(5910ft)
CON	V5/A599/W44	CON at S0420(FL138) FUSU at S0330(FL108) or S0360 FL118 SAREX at S0330(FL108) or S0360 FL118 NLG at S0360(FL118) or S0330(FL108) (RWY34)	CON	34	CON6A CON7A POU6A POU7A POU8A	MCU (IAF)/2100m(6890ft)
POU	A599/B330/W90/R47 3/W19	POU at S0330(FL108) or S0360(FL118) SAREX at S0330(FL108) or S0360 FL118 NLG at S0360(FL118) or S0330(FL108) (RWY34)	POU	16	NLG5A NLG6A NLG7A CON9A POU9A POU1A	NLG (IAF)/2100m(6890ft)
NLG	W6/W18/W509/V19	NLG at S0360(FL118) or S0330(FL108) (RWY34)	NLG			

## LLZ/DME RWY16: (Use LLZ/DME Z unless otherwise requested by pilot)

IAP	IAF/ALT	IF/ALT	LOC FREQ.	SPEED CONTROL
LLZ/DME z	MC516/1800m	D9.0-R218 MCS/2500ft	MCS/111.700	MAX APCH turning speed 190KT

## ILS RWY34: (Use ILS Z unless otherwise requested by pilot)

IAP	IAF/ALT	IF/ALT	ILS FREQ.
ILS Z	HAZEL/FL110 MCU/2100m UJ/2400m R164MCU-R206CH/6000ft	PAPA/3000ft	MCN/109.700

## Squawk Code Assignment:

IFR Departure	VFR Departure	Others
3521-3537	3521-3537	5201-5257

# VHHX – Runway 13/31 (H24)

SID	RWY	Exit Fix	Exit Route	Available Cruising Flight Level	Direction	Reaching Cruising Level	
BEKOL1A	13	BEKOL	A461	Mainland China RVSM Levels	Guangzhou FIR	BEKOL at S0480-(FL157) or above	
BEKOL2C	31			S0420-(FL138) S0450-(FL148)	Landing ZGGG	BEKOL	
				S0180-(5900ft)	Landing ZGSZ		
DOTMI1A	13	DOTMI	A470	290 330 350 390	Guangzhou FIR	SOUSA (42 NM before DOTMI)	
				S0450-(FL148)	Landing ZGOW		
DOTMI2C	31			S0630-(FL207) S0690-(FL226)	Landing ZSAM, ZSQZ		
		S0690-(FL226) S0750-(FL246) S0810-(FL266) 290	Landing ZSFZ, ZSWY				
ELATO1A	13	ELATO	A1	Odd number flight levels at or below FL270	Taipei FIR	20nm before ELATO	
ELATO2C	31		G581	Odd number flight levels at or below FL270			
ENVAR1A	13	ENVAR	M750	Eastbound RVSM FL410 FL450 FL490	Taipei FIR	ENVAR	
ENVAR2C	31						
NOMAN1A	13	NOMAN	A461	290 330 370 410	Manila FIR	20nm before NOMAN	
NOMAN1B			M501	290 330 370 410			
NOMAN2C	31						
NOMAN2D							
SABNO1A	13	SABNO	A583	290 330 370 410	Manila FIR	20nm before SABNO	
SABNO1B							
SABNO2C	31						
SABNO2D							
SIKOU1A	13	SIKOU	A202	S1040-(FL341) S1160-(FL381) S1220-(FL401)	Points beyond ASSAD	DONKI (41nm before SIKOU)	
				S0660-(FL217) S0720-(FL236)	Landing ZJHK		
				S0840-(FL276)	Landing ZJSY		
SIKOU2C	31		R339	Mainland China Westbound RVSM Levels	Points beyond ZGNN		
SIKOU2E					S0630-(FL207)		Landing ZGZJ, ZGNU
					S0810-(FL266) S890-(FL291)		Landing ZGBH, ZGNN
IDOS1A	13	IDOSI	A1/(P901)	280 300 340 380 400 430	Sanya FIR	SURFA (23 NM before IDOSI)	
IDOS1B							
IDOSI2C	31						
IDOSI2D							
EPDOS1A	13	EPDOS	L642	280 310 320 350 360 390 400	Sanya FIR	EPDOS	
EPDOS2C	31						

**Arrival:**

From fix	Arrival routes	STAR (13)	STAR (31)	Descent planning	Speed Control	IAP
DOTMI	DOTMI-MAGOG-ALPHA-CH	MAGOG13	MAGOG31	<b>RWY13</b> Cross CH DME 30NM at FL140 or below	<b>RWY13</b> 250KIAS within CH DME 30NM 210KIAS below 6000FT	<b>IGS13</b> CH(IAF)/8000FT GOLF/6000FT Intercept at 4500FT
ELATO	ELATO-MAGOG-ALPHA-CH					
NOMAN	NOMAN-CH	NOMAN13	NOMAN31	<b>RWY31</b> Cross CH DME 50NM at FL130 Cross WHISKEY at 7000FT	<b>RWY31</b> 250KIAS with TD DME 30NM 210KIAS below 5000FT 180 KIAS by LIMA	<b>ILS31</b> LIMA(IAF)/4500FT Intercept at TH or TP/2000FT
SABNO	SABNO-DELTA-CH	SABNO13	SABNO31			
DUMOL	DUMOL-CH	DUMOL13	DUMOL31	MIKE/FL280, then same as above		
IDOSI	IDOSI-CHALI-CH	IDOSI13	IDOSI31			
SIKOU	SIKOU-CHALI-CH	SIKOU13	SIKOU31			
POU/TAMOT	(POU)-TAMOT-MIKE-CHALI-CH	TAMOT13	TAMOT31			

**Squawk Code Assignment:**

IFR Departure	VFR Departure	Others
5301-5377	5261-5277	5201-5257